



**LEGEND:**

- AB = ANGLE BRACKET TO PROJECT SPECIFICATIONS
- BR = BACKING ROD & SEALANT TO PROJECT SPECIFICATIONS
- CS = CONCRETE SUPPORT SLAB/BEAM/WALL
- SSA = SUPERCOAT™ SUPERBOND ADHESIVE
- HWP = HEBEL® SUPERCRETE™ HORIZONTAL WALL PANELS
- LP = HEBEL® SUPERCRETE™ HORIZONTAL LINTEL PANEL
- NPF = NOTCH PANEL & FILL AS PER SPECIFICATIONS
- SAB = HEBEL® SLOTTED ANGLE BRACKET, REF TO DETAILS
- SP = HEBEL® SUPERCRETE™ HORIZONTAL SILL PANEL
- SSD = STAINLESS STEEL DOWELS, REF TO DETAILS
- TBM = DPC OR EQUIVALENT BOND BREAKER & THICK BEAD MORTAR
- VWP = HEBEL® SUPERCRETE™ VERTICAL WALL PANEL

**Hebel**  
**Supercrete**

Title: CIWS Multiple Panel Width Opening  
Section A-A Detail

Date: October 2011

Scale: N.T.S.

Detail No. 20.3.4

This drawing must be read in conjunction with the Supercrete Commercial & Industrial Wall Systems Design Guide